

My ProHeat 2X® Revolution® Pet Pro Carpet Cleaner has no spray to CleanShot | Support

- Activate CleanShot with on/off pedal (just above the recline pedal)
 - Will flow only when the CleanShot pedal is on and unit is reclined
 - Will flow when motor is either on or off, but flow is stronger when unit is on
- Priming allows fluid to flow through system:
- Turn off and unplug machine and place in upright position
 - Fill clean water tank
 - Remove the front nozzle by lifting under the hose access door



- To prime, use a standard ball point pen, press into the small circular opening until water comes out
- Replace nozzle by lining up tabs on front edges of foot
- Push on nozzle until it clicks into place
- Retry CleanShot by plugging in, turning on, & reclining unit
- If still not spraying, contact us